



CÓDIGO	DESCRIPCIÓN	PRESENTACIÓN
7795587005014	ABRELATAS MANIJA LOKEMEYER 501	1
7795587005021	ABRELATAS MARIPOSA LOKEMEYER 502	1
7795587005112	ABRELATAS TRES EN UNO LOKEMEYER 511	1
7795587005069	ABRELATAS UNAS LOKEMEYER x1	1
7795587005045	AFILADOR CUCHILLOS	1
7795587005434	AHUECA FRUTAS LOCKMEYER 543	1
7795587005427	AHUECA PAPAS LOEKEMEYER 542	1
7795587003454	ATIZADOR LOKEMEYER 345 (CROMADO)	1
7795587005458	BATIDOR CHICO X2 LOKEMEYER 545	1
7795587005441	BATIDOR PERA ALAMBRE LOEKEMEYER 544	1
7795587005151	BATIDOR RESORTE LOKEMAYER 515	1
314106	COLADOR N.08 METAL LOCKEMAYER 026	1
7795587000279	COLADOR N.10 METAL LOCKEMAYER 027	1
7795587000286	COLADOR N.13 METAL LOCKEMAYER 028	1
314105	COLADOR N.16 METAL LOCKEMAYER 029	1
314104	COLADOR N.20 METAL LOCKEMAYER 030	1
7795587005625	CORTA PIZZA ACERO LOCKEMEYER 562	1
7795587005465	CORTA QUESO LOCKEMEYER 546	1
7795587005595	CORTA RAVIOLES ACERO LOCKEMEYER 559	1
000000031398	CORTA TORTA de acero x 1	1
7795587005472	CORTA TORTA LOKEMEYER 547	1
7798005433062	CUCHARA CALADA INOX.LOKEMEYER	1
7795587003904	CUCHARA CALADA NYLON LOKEMEYER 390	1
7795587005328	CUCHARA HELADO PLASTICA LOKEMEYER 532	1
7795587003515	CUCHARA PULPO NYLON LOKEMEYER 351	1
7795587003911	CUCHARA SPAGUETTI TEFLON LOKEMEYER 391	1
7795587003072	CUCHARON INOXIDABLE LOKEMEYER 307	1
7795587003928	CUCHARON TEFLON LOKEMEYER 392	1
7795587005199	CUCHILLO PARA UNTAR ACERO X2 LOKEMEYER 519	1
7795587005786	DESCAROZADOR ACEITUNAS LOKEMEYER 578	1
7795587003959	DESCORAZONADOR MANZANA LOEKEMEYER 395	1
7795587005168	DESTAPADOR CORONA X2 LOKEMEYER 516	1
7795587003966	ENRULADOR MANTECA LOKEMEYER 396	1
7795587003010	ESPATULA ANCHA LOKEMEYER	1
7795587003935	ESPATULA CALADA NYLON LOKEMEYER 393	1
7795587003270	ESPATULA GOMA GASTRONOMICA LOKEMEYER 327	1
7795587003003	ESPATULA INOXIDABLE LOKEMEYER 300	1
7795587003942	ESPATULA LISA NYLON LOKEMEYER 394	1
7795587002020	ESPATULA MADERA LOKEMEYER 202	1
7795587006516	ESPATULA NYLON ANCHA P/TEFLON LOKEMAYER 651	1
7795587006509	ESPATULA NYLON FINA P/TEFLON LOKEMEYER 650	1
7795587003546	ESPATULA PALA NYLON LISA 354	1
7795587003263	ESPATULA PLASTICA 3 USOS LOKEMEYER 326	1
7795587003256	ESPATULA PLASTICA LOKEMEYER 325	1
7795587002037	ESPATULA REPOSTERA LOKEMEYER 203	1
7795587003034	ESPUMADERA LOKEMEYER	1
7795587005359	LIMPIA MAMADERA Y VASOS LOEKEMEYER	1
7795587003126	PALA DE TORTA ACERO LOCKEMEYER 312	1
7795587005090	PALETA BATIDORA LOKEMEYER 509	1
7795587005144	PELA NARANJAS LOKEMEYER 514	1
7795587005137	PELA PAPAS CABO METAL LOCKEMAYER 513	1
7795587005052	PELA PAPAS CABO PLASTICO LOKEMEYER 505	1
7795587005380	PELA Y PICA AJOS LOKEMEYER 537	1
7795587005601	PINZA ALAMBRE CHICA LOKEMEYER 560	1
7795587005618	PINZA ALAMBRE GRANDE LOKEMEYER 561	1
7795587005960	PINZA ENSALADA ACERO LOKEMEYER 596	1
7795587005953	PINZA FIAMBRE ACERO LOCKEMEYER 595	1
7795587005946	PINZA FIDEOS LOKEMEYER 594	1
7795587005175	PINZA GASTRONOMICA LOCKEMAYER 517	1
7795587005632	PINZA HAMBURGUESAS LOCKEMEYER 563	1
7795587005656	PINZA HIELO ACERO INOXIDABLE 565	1
7795587003096	PISA PAPAS ACERO LOECKEMEYER X1	1
7795587003252	RALLADOR CHICO LOKEMEYER	1
7795587003218	RALLADOR CILINDRICO LOKEMEYER 321	1

7795587003201	RALLADOR MEDIA CANA LOKEMEYER 320	1
7795587003294	RALLADOR QUESO LOKEMEYER 329	1
7795587005076	ROMPENUEZ LOKEMEYER 507	1
7795587005311	SACACORCHO COMBINADO LOEKEMEYER 531	1
7795587005236	SACACORCHO DOBLE ALETA LOKEMEYER 523	1
7795587005205	SACACORCHO T/MOZO LOCKEMEYER 520	1
7795587005274	SACACORCHOS T/MOZO LOKEMEYER 527	1
7795587005083	SACAFUENTES ARTICULADO 508	1
7795587003225	TENEDOR COPETIN X6 322	1
7795587002013	TENEDOR MADERA C/MANGO LOKEMEYER 201	1